

KINETIC NEOGAITER BOOT FOOT (CLEATED SOLE)

Item No
H137

Waders Size Chart

Choosing the right size is the key for optimal comfort and performance. The right fit must be snug but not too tight. Too tight fit can cause stretching of the seams and result in leakage.

The sizes are available in Standard. An average built person's starting point is the Standard size.

To give you an indication of your size, follow the measurements shown in the tables below, using the 6 measuring points being Waist, Hip, Thigh, Inseam, Outseam and Sock inside length. This will give you a fairly good idea about the size you need, but trying the waders at your local retailer is always recommended.

KINETIC WADERS SIZE CHART

Standard	38-39	40-41	42-43	44-45	46-47	48-49
Chest cm	97	105	105	112	114	117
Hip cm	107	112	115	123	124	126
Thigh cm	66	68,5	70	74	74,5	75,5
Inseam cm	83	84	89	93	98	100
Outseam cm	129	133	136	144	153	157
Boot inside length cm	26,5	27,5	28,5	29,5	31,5	32

